

ÍNDICE **INDEX**

INDIOL			
CODE		CODE	
CÓDIGO	Pág.	CÓDIGO	Pág.
A-AD-1.6-BNC-00-75	15	A-AD-SMA-SMC-07-50	8
-1.6-BNC-03-75	11	-SMA-TNC-00-50	17
-1.6-BNC-07-75	4	-SMA-TNC-03-50	14
-1.6-TNC-07-75	4 4	-SMA-TNC-07-50	8
-5/8-F-07-75 -716-N-00-50	15	-SMB-BNC-07-50 -SMB-MCX-07-50	8
-716-N-03-50	11	-SMB-N-07-50	8
-716-N-07-50	4	-SMB-SMA-07-50	8
-BNC-1.6-07-75 -BNC-F-03-75	4 11	-SMB-SMC-00-50 -SMB-SMC-03-50	17 14
-BNC-F-07-75	4	-SMB-SMC-07-50	8
-BNC-FME-03-50	4	-SMB-TNC-00-50	17
-BNC-MCX-00-50 -BNC-MCX-03-50	15 11	-SMB-TNC-03-50 -SMC-BNC-07-50	14 8
-BNC-MCX-07-50	4	-SMC-MCX-07-50	9
-BNC-N-00-50	15	-SMC-N-07-50	9
-BNC-N-00-75 -BNC-N-03-50	15 11	-SMC-SMA-07-50 -SMC-SMB-07-50	9
-BNC-N-03-75	11	-SMC-TNC-00-50	17
-BNC-N-07-50	4	-SMC-TNC-03-50	14
-BNC-N-07-75 -BNC-SMA-00-50	4 15	-SMC-TNC-07-50 -TNC-1.6-07-75	9
-BNC-SMA-03-50	11	-TNC-BNC-07-50	ý
-BNC-SMA-07-50	5_	-TNC-BNC-07-75	9
-BNC-SMB-00-50 -BNC-SMB-03-50	15 11	-TNC-MCX-07-75 -TNC-N-07-75	9 10
-BNC-SMB-07-50	5	-TNC-SMA-07-50	10
-BNC-SMC-00-50	15	-TNC-SMB-07-50	10
-BNC-SMC-03-50	12	-TNC-SMC-07-50	10
-BNC-SMC-07-50 -BNC-TNC-00-50	5 15	-TNC-UHF-03-50 -TNC-UHF-07-50	14 7
-BNC-TNC-00-75	15	-UHF-BNC-07-50	10
-BNC-TNC-03-50 -BNC-TNC-03-75	12 12	-UHF-N-07-50 -UHF-TNC-07-50	10
-BNC-TNC-07-50	5	-UHF - INC-U7-30	10
-BNC-TNC-07-75	5		
-BNC-UHF-00-50	16 12		
-BNC-UHF-03-50 -BNC-UHF-07-50	5		
-F-BNC-07-75	5		
-F-TNC-03-75 -F-TNC-07-75	12 5		
-FME-N-03-50	12		
-FME-SMA-03-50	12		
-FME-TNC-03-50 -FME-UHF-03-50	12 12		
-MCX-BNC-07-50	5		
-MCX-N-00-50	16		
-MCX-N-03-50 -MCX-N-07-50	13 6		
-MCX-N-07-30	16		
-MCX-SMA-03-50	13		
-MCX-SMA-07-50 -MCX-SMB-00-50	6 16		
-MCX-SMB-00-50	13		
-MCX-SMB-07-50	6		
-MCX-SMC-00-50 -MCX-SMC-03-50	16 13		
-MCX-SMC-03-50	6		
-MCX-TNC-00-50	16		
-MCX-TNC-03-50 -N-716-07-50	13 6		
-N-BNC-07-50	6		
-N-BNC-07-75	6		
-N-F-07-75 -N-MCX-07-50	6 6		
-N-SMA-00-50	16		
-N-SMA-03-50	13		
-N-SMA-07-50 -N-SMB-00-50	7 16		
-N-SMB-03-50	13		
-N-SMB-07-50	7		
-N-SMC-00-50 -N-SMC-03-50	17 13		
-N-SMC-07-50	7		
-N-TNC-00-50	17		
-N-TNC-00-75 -N-TNC-03-50	17 13		
-N-TNC-03-75	13		
-N-TNC-07-50	7		
-N-TNC-07-75 -N-UHF-00-50	7 17		
-N-UHF-03-50	14		
-N-UHF-07-50 -SMA-PNC-07-50	7 7		
-SMA-BNC-07-50 -SMA-MCX-07-50	7		
-SMA-N-07-50	7		
02-00-8M2-AM2-	17		
-SMA-SMB-03-50 -SMA-SMB-07-50	14 8		
-SMA-SMC-00-50	17		
-SMA-SMC-03-50	14	I	- 1



Adaptadores entre series

Adaptors between series


male=m macho=m
female=f hembra=f

m-m f-f m-f

1.6/	′ 5.6	5/	8"	7/	16	В	١C		-	FN	۸E	м	CX		N	SI	ΛA	SM	иB	SN	ИC	TN	۱C	l ui	4F		
m	f	m	I	m		_	f		f	_	f	m		m	1	m	f	m		m		m	_	m			
						11.1	4.1																4.2			m	1.6/5.6
						4.5	15.1															9.6				f	1.6/5.6
									4.3																	m	5/8"
																										f	3/8
														11.2	4.4											m	7/16
														6.6	15.2											f	//10
11.1	4.1							11.3	4.6	11.4		11.5	4.7	11.6	4.8	11.7	5 5 1.:	11.8		12.1	5.3	12.2	5.4	12.3	5.5	m	BNC
4.5	15.1							5.6				6.1	15.3	6.7	15.4	7.6	15.5	8.4	15.6	8.10	15.7	9.7	15.8	10.6	16.1	f	BNC
						11.3	5.6								5.8							12.4	5.7			m	F
		4.3				4.6								6.8												f	, r
						11.4								12.5		12.6						12.7		12.8		m	FME
																										f	f
						11.5	6.1							13.1	6.2	13.2	6.3	13.3	6.4	13.4	6.5	13.5				m	мсх
						4.7	15.3							6.9	16.2	7.7	16.3	8.5	16.4	9.1	16.5	9.8	16.6			f	WOX
					6.6	11.6	6.7		6.8	12.5		13.1	6.9		-			13.7							-	m	N
						4.8	15.4	5.8				6.2	16.2			7.8	16.7	8.6	16.8	9.2	17.1	10.1	17.2	10.7	17.3	f	
						11.7	7.6			12.6		13.2	7.7	13.6	7.8			14.2								m	SMA
						5.1	15.5					6.3	16.3	7.1	16.7			8.7	17.4	9.3	17.5	10.2	17.6			f	J
						11.8						-	-		8.6		_			-	-	14.6	-			m	SMB
						-	15.6					-		-	16.8							10.3				f	
						_	8.10					-		_	9.2							14.7				m	SMC
						_	15.7					—			17.1								17.9			f	
						-	9.7			12.7		_	_	-	10.1		_			_	-				10.5	m	TNC
4.2							15.8							 	17.2		17.6	8.9	8.9	9.5				10.8		f	
	9.6					12.3	-			12.8					10.7						-		10.8			m	UHF
						5.5	16.1							7.5	17.3							10.5				f	



Adaptadores macho-hembra




SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
1.6/5.6	BNC	75	A-AD-1.6-BNC-07-75	4.1




	•
	38 [1.496]
ø14 [.551]	

Adaptors male-female


BNC	1.6/5.6	75	A-AD-BNC-1.6-07-75	4.5
m	f	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE




SEF	RIES	Ω	ALFA R CODE	TABLE
m	t		CÓDIGO ALFA`R	TABLA
1.6/5.6	TNC	75	A-AD-1.6-TNC-07-75	4.2




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
BNC	F	75	A-AD-BNC-F-07-75	4.6




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
5/8	F	75	A-AD-5/8-F-07-75	4.3



SEF	RIES	\cap	ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
BNC	мсх	50	A-AD-BNC-MCX-07-50	4.7




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
7/16	N	50	A-AD-716-N-07-50	4.4




SEF	SERIES		ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
BNC	N	50	A-AD-BNC-N-07-50	4.8
BNC	IN .	75	A-AD-BNC-N-07-75	4.0






SEF	RIES	0	ALFA'R CODE	TABLE
m	f	7 7	CÓDIGO ALFA`R	TABLA
BNC	SMA	50	A-AD-BNC-SMA-07-50	5.1




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.2	CÓDIGO ALFA`R	TABLA
BNC	UHF	50	A-AD-BNC-UHF-07-50	5.5


42.3 [1.665]




BNC	SMB	50		5.2
m	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




F	BNC	75	A-AD-F-BNC-07-75	5.6
m	f	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




BNC	SMC	50	A-AD-BNC-SMC-07-50	5.3
m	f	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES	\cap	ALFA'R CODE	TABLE



F	TNC	75	A-AD-F-TNC-07-75	5.7
m	f	77	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
BNC	TNC	50	A-AD-BNC-TNC-07-50	5.4
BNC	TNC	75	A-AD-BNC-TNC-07-75	5.4




SERIES			ALFA'R CODE	TABLE	
m	f	7.7	CÓDIGO ALFA`R	TABLA	
BNC	TNC	BNC TNC	50		5.8
BNC	INC	75	A-AD-F-N-07-75	3.6	







SEF	RIES		ALFA`R CODE	TABLE
m	f	7.2	CÓDIGO ALFA`R	TABLA
MCX	BNC	50	A-AD-MCX-BNC-07-50	6.1




MCX	N	50	A-AD-MCX-N-07-50	6.2
m	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE




m	f	7.7	CÓDIGO ALFA`R	TABLA
мсх	SMA	50	A-AD-MCX-SMA-07-50	6.3




SEF	RIES	Ω	ALFA`R CODE	TABLE
m	f		CÓDIGO ALFA`R	TABLA
МСХ	SMB	50	A-AD-MCX-SMB-07-50	6.4




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.2	CÓDIGO ALFA`R	TABLA
MCX	SMC	50	A-AD-MCX-SMC-07-50	6.5




SEF	RIES	\cap	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
N	7/16	50	A-AD-N-716-07-50	6.6



SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
N BNC	BNC 50	50	A-AD-N-BNC-07-50	6.7
"	BNC	75	A-AD-N-BNC-07-75	0.7





SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
N	F	75	A-AD-N-F-07-75	6.8




SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
N	мсх	50	A-AD-N-MCX-07-50	6.9












N N	UHF	50		7.5
m	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE




SEF	RIES	0	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
N	SMB	50	A-AD-N-SMB-07-50	7.2




m	f	7.7	CÓDIGO ALFA`R	TABLA
SMA	BNC	50	A-AD-SMA-BNC-07-50	7.6




N	SMC	50	A-AD-N-SMC-07-50	7.3
m	f	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE



SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMA	мсх	50	A-AD-SMA-MCX-07-50	7.7




SEF	RIES		ALFA'R CODE	TABLE
m	f	77	CÓDIGO ALFA`R	TABLA
N	TNC	50	A-AD-N-TNC-07-50	7.4
19	INC	75	A-AD-N-TNC-07-75	/ · 4




SEF	RIES		ALFA`R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMA	N	50	A-AD-SMA-N-07-50	7.8







SEF	RIES	വ	ALFA'R CODE	TABLE
m	f	3.2	CÓDIGO ALFA`R	TABLA
SMA	SMB	50	A-AD-SMA-SMB-07-50	8.1




SMA	SMC	50	A-AD-SMA-SMC-07-50	8.2
m	f	72	CÓDIGO ALFA`R	TABLA
SEF	RIES	0	ALFA'R CODE	TABLE




SEF	RIES		ALFA`R CODE	TABLE
m	f	7.2	CÓDIGO ALFA`R	TABLA
SMA	TNC	50	A-AD-SMA-TNC-07-50	8.3




SMB	N	50	A-AD-SMB-N-07-50	8.6
m	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMB	SMA	50	A-AD-SMB-SMA-07-50	8.7




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMB	SMC	50	A-AD-SMB-SMC-07-50	8.8




SEF	RIES	0	ALFA'R CODE	TABLE
m	f	3.2	CÓDIGO ALFA`R	TABLA
SMB	BNC	50	A-AD-SMB-BNC-07-50	8.4



SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMB	TNC	50	A-AD-SMB-TNC-07-50	8.9





SEF	RIES	Ω	ALFA'R CODE	TABLE
m	f		CÓDIGO ALFA`R	TABLA
SMB	мсх	50	A-AD-SMB-MCX-07-50	8.5



SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMC	BNC	50	A-AD-SMC-BNC-07-50	8.10









SEF	RIES	0	ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
SMC	мсх	50	A-AD-SMC-MCX-07-50	9.1


SEF	RIES		ALFA'R CODE	TABLE
m	f	77	CÓDIGO ALFA`R	TABLA
SMC	TNC	50	A-AD-SMC-TNC-07-50	9.5






SEF	RIES	0	ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
SMC	N	50	A-AD-SMC-N-07-50	9.2


SEF	RIES		ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
TNC	1.6/5.6	75	A-AD-TNC-1.6-07-75	9.6





SEF	RIES		ALFA`R CODE	TABLE
m	f	77	CÓDIGO ALFA`R	TABLA
SMC	SMA	50	A-AD-SMC-SMA-07-50	9.3

SEF	RIES)	ALFA'R CODE	TABLE	
m	f	7.7	CÓDIGO ALFA`R	TABLA	
TNC	DNC	C BNC 5	50	A-AD-TNC-BNC-07-50	9.7
TNC	BNC	75	A-AD-TNC-BNC-07-75	9.7	




	34 [1.338]
[.552]	
414	


SEF	RIES		ALFA`R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
SMC	SMB	50	A-AD-SMC-SMB-07-50	9.4

SEF	RIES)	ALFA'R CODE	TABLE
m	f	77	CÓDIGO ALFA`R	TABLA
TNC	мсх	50	A-AD-TNC-MCX-07-50	9.8







SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
TNC	N.	NC N 50	A-AD-TNC-N-07-50	10.1
INC	IN	75	A-AD-TNC-N-07-75	5.




TNC	UHF	50	A-AD-TNC-UHF-07-50	10.5
m	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




TNC	SMA	50	A-AD-TNC-SMA-07-50	10.2
m	f	77	CÓDIGO ALFA`R	TABLA
SEF	RIES	$ \cap $	ALFA'R CODE	TABLE




SEF	RIES		ALFA'R CODE	TABLE
m	f	7 2	CÓDIGO ALFA`R	TABLA
UHF	BNC	50	A-AD-UHF-BNC-07-50	10.6




SEF	RIES	വ	ALFA'R CODE	TABLE
m	f	32	CÓDIGO ALFA`R	TABLA
TNC	SMB	50	A-AD-TNC-SMB-07-50	10.3



SEF	RIES		ALFA'R CODE	TABLE
m	f	7 Z	CÓDIGO ALFA`R	TABLA
UHF	N	50	A-AD-UHF-N-07-50	10.7



SEF	RIES)	ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
TNC	SMC	50	A-AD-TNC-SMC-07-50	10.4




SEF	RIES		ALFA'R CODE	TABLE
m	f	7.7	CÓDIGO ALFA`R	TABLA
UHF	TNC	50	A-AD-UHF-TNC-07-50	10.8




Adaptadores macho-macho


Adaptors male-male




SEF	SERIES		ALFA`R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
1.6/5.6	BNC	75	A-AD-1.6-BNC-03-75	11.1




SEF	RIES		ALFA`R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
BNC	мсх	50	A-AD-BNC-MCX-03-50	11.5




SEF	RIES		ALFA`R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
7/16	N	50	A-AD-716-N-03-50	11.2




SEF	RIES)	ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
BNC	N	50	A-AD-BNC-N-03-50	11.6
BNC	IN	50	A-AD-BNC-N-03-50	11.0




SEF	RIES		ALFA'R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
BNC	F	75	A-AD-BNC-F-03-75	11.3



SEF	RIES	0	ALFA'R CODE	TABLE
m	m	7 2	CÓDIGO ALFA`R	TABLA
BNC	SMA	50	A-AD-BNC-SMA-03-50	11.7




SEF	RIES		ALFA`R CODE	TABLE
m	m	72	CÓDIGO ALFA`R	TABLA
BNC	FME	50	A-AD-BNC-FME-03-50	11.4




SEF	RIES)	ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
BNC	SMB	50	A-AD-BNC-SMB-03-50	11.8







SEF	RIES		ALFA`R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
BNC	SMC	50	A-AD-BNC-SMC-03-50	12.1




SEF	RIES		ALFA`R CODE	TABLE
m	m	7 2	CÓDIGO ALFA`R	TABLA
FME	N	50	A-AD-FME-N-03-50	12.5




SEF	SERIES		ALFA`R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
BNC	TNC	50	A-AD-BNC-TNC-03-50	12.2
BINC	INC	75	A-AD-BNC-TNC-03-75	12.2




SEF	RIES		ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
FME	SMA	50	A-AD-FME-SMA-03-50	12.6




SEF	RIES		ALFA'R CODE	TABLE
m	m	7.2	CÓDIGO ALFA`R	TABLA
BNC	UHF	50	A-AD-BNC-UHF-03-50	12.3



SEF	RIES	Ω	ALFA'R CODE	TABLE
m	m		CÓDIGO ALFA`R	TABLA
FME	TNC	50	A-AD-FME-TNC-03-50	12.7




SEF	RIES		ALFA'R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
F	TNC	75	A-AD-F-TNC-03-75	12.4




SEF	SERIES		ALFA'R CODE	TABLE
m	m	7 2	CÓDIGO ALFA`R	TABLA
FME	UHF	50	A-AD-FME-UHF-03-50	12.8







SEF	RIES		ALFA'R CODE	TABLE
m	m	7.2	CÓDIGO ALFA`R	TABLA
MCX	N	50	A-AD-MCX-N-03-50	13.1




мсх	SMA	50	A-AD-MCX-SMA-03-50	13.2
m	m	7.7	CÓDIGO ALFA`R	TABLA
SEF	SERIES		ALFA'R CODE	TABLE




мсх	SMB	50	A-AD-MCX-SMB-03-50	13.3
m	m	7 2	CÓDIGO ALFA`R	TABLA
SEF	SERIES		ALFA`R CODE	TABLE




мсх	SMC	50	A-AD-MCX-SMC-03-50	13.4
m	m	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




m m	7 2	CÓDIGO ALFA`R	TABLA
SERIES		ALFA'R CODE	TABLE




SEF	RIES		ALFA`R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
N	SMA	50	A-AD-N-SMA-03-50	13.6



N	SMB	50	A-AD-N-SMB-03-50	13.7
m	m	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE





N	SMC	50	A-AD-N-SMC-03-50	13.8
m	m	7 Z	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE



SERIES			ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
N TNC	N TNC 50	50		13.9
_ N	INC	75	A-AD-N-TNC-03-75	13.9









SEF	RIES		ALFA`R CODE	TABLE
m	m	7 2	CÓDIGO ALFA`R	TABLA
N	UHF	50	A-AD-N-UHF-03-50	14.1


H	RIES	Ω	ALFA`R CODE	TABLE
m	m	""	CÓDIGO ALFA`R	TABLA
SMB	SMC	50	A-AD-SMB-SMC-03-50	14.5






SEF	RIES		ALFA'R CODE	TABLE
m	m	77	CÓDIGO ALFA`R	TABLA
SMA	SMB	50	A-AD-SMA-SMB-03-50	14.2


SEF	RIES		ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
SMB	TNC	50	A-AD-SMB-TNC-03-50	14.6






	SMC		A-AD-SMA-SMC-03-50	
m	m	7 2	CÓDIGO ALFA`R	TABLA
SER	IIES)	ALFA'R CODE	TABLE

SEF m	m	Ω	ALFA`R CODE CÓDIGO ALFA`R	<i>TABLE</i> TABLA
SMC	TNC	50	A-AD-SMC-TNC-03-50	14.7






SEF	SERIES		ALFA'R CODE	TABLE
m	m	7 2	CÓDIGO ALFA`R	TABLA
SMA	TNC	50	A-AD-SMA-TNC-03-50	14.4

SEF	RIES)	ALFA'R CODE	TABLE
m	m	7.7	CÓDIGO ALFA`R	TABLA
TNC	UHF	50	A-AD-TNC-UHF-03-50	14.8




Adaptadores hembra-hembra




SEF	RIES		ALFA'R CODE	TABLE
f	f	7 2	CÓDIGO ALFA`R	TABLA
1.6/5.6	BNC	75	A-AD-1.6-BNC-00-75	15.1


Adaptors female-female




BNC	SMA	50	A-AD-BNC-SMA-00-50	15.5
f	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




7/16	NI NI	50	CÓDIGO ALFA`R A-AD-716-N-00-50	15.2
£	ŧ	3 Z	CÓDICO AL ENID	TARLA
SEF	RIES		ALFA'R CODE	TABLE




BNC	SMB	50	A-AD-BNC-SMB-00-50	15.6
f	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE




SEF	RIES	0	ALFA'R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
BNC	MCX	50	A-AD-BNC-MCX-00-50	15.3



SEF	SERIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
BNC	SMC	50	A-AD-BNC-SMC-00-50	15.7





SEF	RIES		ALFA'R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
BNC	N	50	A-AD-BNC-N-00-50	
	IN IN	75	A-AD-BNC-N-00-75	



SEF	SERIES		ALFA'R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
BNC	TNC	50	A-AD-BNC-TNC-00-50	15.0
	INC	75	A-AD-BNC-TNC-00-75	TABLA 15.8









SEF	RIES		ALFA`R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
BNC	UHF	50	A-AD-BNC-UHF-00-50	16.1


1	мсх	SMC	50	A-AD-MCX-SMC-00-50	16.5
	f	f	7.7	CÓDIGO ALFA`R	TABLA
	SEF	RIES		ALFA'R CODE	TABLE






SEF	RIES		ALFA`R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
MCX	N	50	A-AD-MCX-N-00-50	16.2


мсх	TNC	50	A-AD-MCX-TNC-00-50	16.6
f	f	7 2	CÓDIGO ALFA`R	TABLA
SEF	RIES		ALFA'R CODE	TABLE






MCX	SMA	50	A-AD-MCX-SMA-00-50	16 3
f	f	7.7	CÓDIGO ALFA`R	TABLA
SEF	RIES)	ALFA'R CODE	TABLE

SEF	RIES		ALFA`R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
N	SMA	50	A-AD-N-SMA-00-50	16.7







SEF	RIES		ALFA'R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
МСХ	SMB	50	A-AD-MCX-SMB-00-50	16.4

SEF	RIES		ALFA`R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
N	SMB	50	A-AD-N-SMB-00-50	16.8







SEF	RIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
N	SMC	50	A-AD-N-SMC-00-50	17.1




SEF	RIES		ALFA'R CODE	TABLE
f	f	7 2	CÓDIGO ALFA`R	TABLA
N	TNC	50	A-AD-N-TNC-00-50	17.2
l IN	INC	75	A-AD-N-TNC-00-75	17.2




SEF	RIES)	ALFA'R CODE	TABLE
f	f	7 2	CÓDIGO ALFA`R	TABLA
N	UHF	50	A-AD-N-UHF-00-50	17.3




SEF	RIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
SMA	SMB	50	A-AD-SMA-SMB-00-50	17.4




SEF	RIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
SMA	SMC	50	A-AD-SMA-SMC-00-50	17.5




SEF	RIES		ALFA'R CODE	TABLE
f	f	77	CÓDIGO ALFA`R	TABLA
SMA	TNC	50	A-AD-SMA-TNC-00-50	17.6



SEF	RIES		ALFA`R CODE	TABLE
f	f	7 2	CÓDIGO ALFA`R	TABLA
SMB	SMC	50	A-AD-SMB-SMC-00-50	17.7



SEF	SERIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
SMB	TNC	50	A-AD-SMB-TNC-00-50	17.8



SEF	RIES		ALFA'R CODE	TABLE
f	f	7.7	CÓDIGO ALFA`R	TABLA
SMC	TNC	50	A-AD-SMC-TNC-00-50	17.9

